
4. ELECTRICAL CONNECTIONS

CABLE COLOUR	CONNECTION
BROWN	POSITIVE KEY CONTACT
BLACK	ENGINE GROUND
GREY	IGNITION IMPULSES
GREEN	GAS SOLENOID VALVES
WHITE	PETROL SOLENOID VALVE
WHITE/BLACK	TANK LEVEL/RESERVE

NOTE:

The grey wire can be indifferently connected to:

- the ignition coil negative;
- the square wave signals available between the ignition ECU and the corresponding power module (provided that they have sufficient amplitude) or direct to the revolution counter;
- twisted with some turns around high voltage cables.



WARNING

M.T.M. S.r.I. declines all responsibility for any improper installation or use of this product that may cause serious injury and/or property damage.